



Wheel spat construction.
Use internal glue strip -
colored area helps to hide
any possible gaps.

RECOMMENDED BUILD SEQUENCE

1. Fuselage - do not glue front lower fuselage yet.
2. Horizontal and vertical tail - attach to fuselage.
3. Cockpit interior, headrest and windscreens.
4. Wing - slide into fuselage - glue front lower fuselage.
5. Wing fillets - curve gently and start glueing from the back. Attach to wing and fuselage in small lengths only - do not try to fix in one run.
6. Engine cowling and propellor.
7. Undercarriage.

